
MDM-H
MOVING DOOR MECHANISM WITH CLUTCH




UK +44 (0) 1438 833577 **US** +1 (603) 742 9181
www.**FUTUREAUTOMATION**.NET

TECHNICAL SHEET
ISSUE 001
SHEET 1


MDM-H
MOVING DOOR MECHANISM WITH CLUTCH

GENERAL DIMENSIONS





DETAIL B
SCALE 1 : 5

MDM is fixed from underneath through the mounting holes, Fixing head to be no deeper than 10mm [3/8"]



SECTION A-A






UK +44 (0) 1438 833577 **US** +1 (603) 742 9181
www.**FUTUREAUTOMATION**.NET

TECHNICAL SHEET
ISSUE 001
SHEET 2

MDM-H
MOVING DOOR MECHANISM WITH CLUTCH

PANEL DIMENSIONS


OPEN POSITION



Hanger Adjustment
Loosen the nuts and raise
or lower to desired position

DETAIL C

CLOSED POSITION




UK +44 (0) 1438 833577 **US** +1 (603) 742 9181
www.**FUTUREAUTOMATION**.NET

TECHNICAL SHEET
ISSUE 001
SHEET 3


MDM-H
MOVING DOOR MECHANISM WITH CLUTCH

SWITCH ADJUSTMENT



The limit switches can be adjusted using an allen key. Undo the bolts and slide switch to desired position.

DETAIL D
SCALE 1 : 2



UK +44 (0) 1438 833577 **US** +1 (603) 742 9181
www.**FUTUREAUTOMATION**.NET

TECHNICAL SHEET
ISSUE 001
SHEET 4